GAS-101 基础款英文说明书 尺寸 320×130mm, 四折页 风琴折

Dear user: Before using this product, please read this manual carefully and keep it properly for future reference.

01/Product Parameter

- Size：87×87×285mm
- Weight：660g
- Voltage：Type-C/5V/2A
- Capacity：120ml
- Power：1.5W
- Coverage：200m³

02/Equipment Installation



Pull the atomizer upwards from the casing to remove the entire assembly.



Fill the bottle with fragrance oil, screw it on in the direction of the arrow, and put it back into the device.

03/Package Contents

Equipment×1、Remote control×1、Type-C Power cable×1、User manual×1、Atomizer accessories×1、Gasket×1、After-sales Card

04/Indicator instruction (Remote Control Mode)



High:
3 White lights, pump on for 15s, off for 60s. Default timer: 8 hours.

Medium:
2 white lights, pump on for 15s, off for 180s. Default timer: 8 hours.

Low:
1 white light, pump on for 15s, off for 300s. Default timer: 8 hours.

05/Indicator instruction(Bluetooth Mode)



High:
3 blue lights, pump on for 15s, off for 60s. Default timer: 08:00-22:00.

Medium:
2 blue lights, pump on for 15s, off for 180s. Default timer: 08:00-22:00.

Low:
1 blue light, pump on for 15s, off for 300s. Default timer: 08:00-22:00.

06/Remote instruction



Intensity Level - High / Reset Button:
-Short press to activate High Level: 15s on, 60s off, with a default timer of 8 hours.
-Press and hold for 5s to reset: defaults to 15s on, 300s off, 8-hour timer.

Intensity Level - Medium:
Short press to activate Medium Level: 15s on, 180s off, with a default timer of 8 hours.

Intensity Level - Low:
Short press to activate Low Level: 15s on, 300s off, with a default timer of 8 hours.

Power Switch:
Long press for 2 seconds to turn On / Off (Air Pump & Light)
Remote Control Pairing:
Press and hold the power switch on the remote while plugging in the power. The light will flash green to indicate successful pairing.

07/Bluetooth Operation Instructions

Go to the Apple App Store or Google Play, search for “Scent Lab”, or scan the QR code below to download and open the app.

Tips：
APP permission settings, including location services and Bluetooth connections, must be authorized for the app to function properly.

① Open the Scent Lab app, go to the homepage, and tap "Start Connection". Wait for the device to load, then select the corresponding device model to connect.







② Mode Setting: 5-segment working mode. Tap any column to customize the weekly schedule, set power-on and power-off times, and adjust the intensity level, etc.



③ Additional settings: Click the top right corner to set the device name, avatar, and password.



09/Concentration & Consumption

Mode	Work time/s	Stop time/s	Consumption(g/h)
Minimum	15s	300s	0.05
Medium	15s	180s	0.08
Maximum	15s	60s	0.22
100% Power	Fully Open	0	1.08

1. The above data is based on the fragrance oil tested: Park Hyatt (density ≥0.95).
2. The above data is for reference only, and the amount of atomization rate may vary when using different fragrance oils.

10/Atomizer Replacement

The atomizer assembly includes the atomizing head, oil bottle, and the relevant atomizing units.
Steps: (1)Unscrew the oil bottle. (2)Wipe off any remaining oil with a dry cloth. (3)Remove the atomizing unit that need replacement. (4)Securely install the new atomizing unit in place.



11/Equipment Maintenance

If the device will not be used for an extended period, clean the nozzle and internal parts by filling the empty oil bottle with 95% industrial alcohol.
Operation:(1)Fill the empty bottle with 95% industrial alcohol. (2)Attach it to the device and turn it on. (3)Let it run for 10–15 minutes, then turn it off. (4)Pour out the alcohol and screw the bottle back onto the machine.

12/Warranty

- The warranty applies only to new machines, not resold or second-hand units.
- We provide a 12-month warranty from the date of purchase for all eligible machines. During the warranty period, we offer repair services and free replacement parts (excluding fragrance oils).
- A warranty card and commercial invoice are required for any service request. Please contact us within the warranty period if any issues occur.
- The following conditions are not covered:

①Damage caused by accidents, fire, or natural disasters.
②Improper use or incorrect operation.
③Damage resulting from unauthorized repairs or modifications.
④Damage incurred during transportation.
⑤Missing warranty card.
⑥Lack of regular maintenance or cleaning.
⑦Damage caused by overloading or operating the machine beyond its recommended working time.
⑧Machines or parts not supplied by us.
⑨Machines not purchased through authorized channels.
⑩Returning the machine without prior approval from the manufacturer.

13/Precautions

- Read the manual carefully and keep it for future reference.
- Empty the bottle during transport to prevent leaks and damage.
- Keep the device upright while filling; do not tilt or invert.
- Do not cover the device while it is in operation to avoid blocking airflow or mist. Make sure the power socket or adapter is not placed above the mist outlet to prevent prolonged exposure to the spray, which could damage the adapter and cause power problems.
- Avoid overloading or damaging power cords and plugs, and ensure the lithium battery is not damaged.
- Do not disassemble the device. Contact us if any issues arise.

SMART SCENT DIFFUSER
USER MANUAL



Standard type